



Australia

L611 - Solar Camp Light | 3 Colour Modes | 2 LED | MARSHMALLOW

> 1300 900 617 hoselink.com.au



USA

USL611 – Solar Camp Lantern | 2 LED

1 833 216 4673 hoselink.com

Cultivating Connections



youtube.com/hoselink

User Manual

L611 - Solar Camp Light 2 LED | Marshmallow

HOSELINK

HOSELINK®

Kit contents

1x Solar Camp Light

1x USB cable

Elevate your outdoor experiences with the Solar Camp Light. Whether you're camping in the wilderness, hosting a backyard soirée, or simply looking to add a touch of magic to your outdoor space.

Lighting modes

The light can be switched between three different lighting modes.

- 1 Dim Light A dim light is displayed continuously from dusk until dawn.
- 2 Bright Light A bright light is displayed continuously from dusk until dawn.
- 3 Colour changing This will cycle through the colours continuously from dusk until dawn.

Activate the light

Press the 'Power' button located on the side of the solar panel to turn the lights on. Once on, press the black button to cycle through each lighting mode until you reach your preferred option. To test the light, hold your hand over the solar panel and check if the light comes on. The solar panel has a built-in intelligent light sensor, which detects darkness, automatically illuminating the light at dusk and turning it off at dawn.

Note: For cloudy days use the USB charge port to charge the light.

Using the light

Either use the hook to hang the light or place it in the desired location with the solar panel facing up. Solar lights need access to direct sunlight for optimum results, preferably 6-8 hours per day. Be sure to clean the solar panel periodically to maintain optimal performance.

Storing the lights

Manually switch the power to OFF. This will preserve the battery and prevent it from fully discharging during extended storage.

Specifications

Plastic and Silica Gel
Monocrystalline
3.2v 2200mAh
Dim: 12 hours Bright: 4 hours Colour changing: 20 hours
Solar: 10 hours USB: 2 hours
3000K
Dim/Bright 8 LED Colour changing: 1 LED

WARNING: DO NOT USE THIS LIGHT UNDERWATER
OR IN LOW-LYING PUDDLES