

⚠ WARNING

- **INGESTION HAZARD:** This product contains a button cell or coin battery.
- **DEATH** or serious injury can occur if ingested.
- A swallowed button cell or coin battery can cause **Internal Chemical Burns** in as little as **2 hours**.
- **KEEP** new and used batteries **OUT OF REACH of CHILDREN**
- **Seek immediate medical attention** if a battery is suspected to be swallowed or inserted inside any part of the body.
- Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate.
- Even used batteries may cause severe injury or death.
- Call local poison control center for treatment information.
- Use only compatible battery types (CR2025) in the product.
- CR2032 batteries have a nominal battery voltage of 3V.
- Non-rechargeable batteries are not to be recharged.
- Do not force discharge, recharge, disassemble, heat above 140°F or incinerate. Doing so may result in injury due



⚠ WARNING

- to venting, leakage or explosion resulting in chemical burns.
- Ensure the batteries are installed correctly according to polarity (+ and -).
- Do not mix old and new batteries, different brands or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries.
- Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations.
- Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children.



For more information visit
hoselink.com

or
Call (833) 216 4673

Cultivating **Connections**

 youtube.com/hoselink

User Manual

MODEL: USL443

Solar Sphere Light
Multi-color | 10in



HOSELINK[®]

The Solar Sphere Light is perfect for adding a burst of color and ambiance to your garden or for livening up an entertaining area. With multiple color and white light options, as well as the ability to control the light wirelessly through the included infra-red remote, the Solar Sphere Light will bring a cheerful glow to your outdoor space.

Kit Contents

- 1 x Solar globe light
- 1 x Remote (CR2025 button battery included)
- 1 x Ground spike

Lighting Modes

The Solar Sphere Light includes 4 lighting modes and 16 colour options. Please note the four lighting modes will cycle through all available colors if selected, while choosing a single-color option will only display that color continuously:

- | | |
|----------|----------|
| 1 Flash | 3 Fade |
| 2 Strobe | 4 Smooth |

Operating the Light

STEP 1 Turn on the light

When first removed from the box, the light will need to be turned on. Press and hold the 'ON/OFF' button located on the base of the light for 3 seconds. This will activate the light.

To turn the light off, hold down the 'ON/OFF' button for another 3 seconds.

Once activated, you can operate the light with the remote, which will also allow you to turn the light on and off. The light has a built-in intelligent light sensor, which detects darkness, automatically illuminating at dusk and turning off at dawn.
NB. The remote will not work unless the light has been first turned on via the button.

STEP 2 Select your lighting mode

To switch lighting modes, you can use the supplied remote or press the 'ON/OFF' button on the base of the light. This will cycle through the modes.

Product Installation – Option A

Placing the light

Simply place the light in the desired location. Be mindful that the solar panel needs access to direct sunlight to charge. The solar panel is located inside the Solar Sphere Light.

Product Installation – Option B

Ground spike

Insert the ground spike into the base of the Solar Sphere Light then push into the ground.

Using the Remote

Once the light has been turned on with the 'ON/OFF' button on the base, you can now use the remote to control the lights. The infra-red remote has a range of up to 5m and must be pointed at the solar light to work effectively. To switch the light off completely, press the black 'OFF' button located in the top right of the remote. This will fully switch the light off so it will no longer automatically turn on at dusk.

To switch the light back on, press the red 'ON' button located next to the 'OFF' button in the top right of the remote. This will turn the light back on and it will continue to automatically light up at dusk and switch off at dawn. The 'ON' and 'OFF' buttons allow you to switch the light on and off without needing to pick up the light to access the 'ON/OFF' button on its base. You can adjust the brightness of the lights with the two buttons located on the top left of the remote. To change the color of the light, simply select the desired color button on the remote.

To change the function of the light, select between 'Flash' 'Strobe' 'Fade' or 'Smooth' on the right-hand side of the remote. The remote comes with a 3-volt CR2025 button battery included. To replace the remote's battery, undo the screw on the back of the remote. Then, hold in the side clip on the battery compartment and pull to remove it. Swap the batteries, then return the compartment to the remote and tighten the screw back into place.

**Dispose of used batteries correctly and safely.
Keep out of reach of children.**