



MODEL: USL511
Stainless Steel Solar Bollard Light
with Motion Sensor | 12 LED

For more information visit

hoselink.com

or call

1 833 216 4673

Cultivating **Connections**

 youtube.com/hoselink



User Manual

MODEL: USL511
Stainless Steel Solar Bollard Light
with Motion Sensor | 12 LED

HOSELINK[®]

Kit Contents

- 1 x Stainless Steel Solar Bollard
- 1 x Ground Spike
- 1 x Hardware Kit (2 x screws, 2 x masonry plugs)

An elegant lighting solution that combines modern design with sustainable technology. With its built-in motion sensor and exceptional luminosity, this solar light is the perfect addition to any outdoor space, providing both style and functionality.

Lighting Modes

- 1 Constant Dim Light** - A dim light is displayed continuously from dusk until dawn.
- 2 Sensor with Dim Light** - A dim light is displayed continuously from dusk until dawn. When motion is detected, the light brightens for 25 seconds before returning to a dim light.
- 3 Sensor with Bright Light** - The light will remain off until motion is detected then the brightest light setting will be activated.

Activate the light

Press and hold the white button on the bollard for 3 seconds to turn the light on or off. Once on, press the white button to cycle through each lighting mode until you reach your preferred option. The solar panel has a built-in intelligent light sensor, which detects darkness, automatically illuminating the light at dusk and turning it off at dawn.

Product Installation

STEP 1 Find a suitable location

Solar lights need access to direct sunlight for optimum results; preferably 6-8 hours per day.

STEP 2 Install Solar Light

Product Installation – Option A

Ground Spike

A.1 Push the spike into the base of the solar light until secured then simply push into soft ground in your desired location.

Product Installation – Option B

Using supplied hardware

- B.1** Use the light to mark holes with a marker pen.
- B.2** For masonry installation use a 5/16" drill bit to drill the two holes. Gently hammer the plugs into place and then secure the screws tightly.
- B.3** For timber, drill 1/8" pilot holes to guide screws into place (plastic plugs are not required).

Specifications

Solar panel	Monocrystalline Silicon
Lithium battery	3.7V / 1200mAh
Operating time	Model 1: 22LM 18H, Model 2: 96LM 5H, Model 3: 188LM 2H
Charge time	8 hours
Light temperature (Kelvins)	3000K
LED lumens	Model 1: 20, Model 2: 90, Model 3: 180
Number of LEDs	12

WARNING: Do not use this light underwater or in low-lying puddles.